


RECOVERY SYSTEM CONNECTION SKETCH



- 1 - SIEVE
- 2 - 150 LT. HOPPER DISCHARGE
- 3 - INJECTOR 2
- 4 - INJECTOR 1
- 5 - MINI CYCLONE DISCHARGE
- 6 - FLUIDISING 2
- 7 - FLUIDISING 1
- 8 - SIEVE OFF - ON
- 9 - MAN. - AUTO

===== WORKING PRINCIPLE =====

WHEN YOU SWITCH ON (8) THE SIEVE 1. VALVE FUNCTION, SIEVE MOTOR START TO WORK AND 150 LT HOPPER START TO DISCHARGE THE AIR FROM ITS OUTLET.
 MANUAL - AUTOMATIC MODE
AUTOMATIC ; MINI CYCLONE DISCHARGE , HIGH CAPACITY INJECTOR 1 AND 2 FLUIDISING 1 AND 2 , WORKS AS SET VALVE AT (SM9)TIMER.
MANUAL ; MINI CYCLONE DISCHARGE , HIGH CAPACITY INJECTOR 1 AND 2 FLUIDISING 1 AND 2 , WORKS CONTINUOUSLY.